




Ring Tones

1. Tap **Menu->Basic->Sound->Ring Tones**.
2. Press  or  to select the desired ring tone.
3. Press the **Set Ring Tones** soft key to accept the change.

Call Mute/Un-mute

Press  to mute the microphone during a call. Press it again to un-mute the call.

Call Hold/Resume

- 1. To place a call on hold:**
Press the **Hold** soft key during an active call.
- 2. To resume the call, do one of the following:**
If there is only a call on hold, Press the **Resume** soft key.
If there is more than one call on hold, tap the desired one and press the **Resume** soft key.


Call Transfer

You can transfer a call in the following ways:


Blind Transfer

1. Press the **Transfer** soft key during an active call. The call is placed on hold.
2. Enter the number you want to transfer the call to.
3. Press the **Transfer** soft key.

Semi-Attended Transfer:

1. Press the **Transfer** soft key during an active call. The call is placed on hold.
2. Enter the number you want to transfer the call to, and then press  or the **Send** soft key.
3. Press the **Transfer** soft key when you hear the ring-back tone.

Attended Transfer:

1. Press the **Transfer** soft key during an active call. The call is placed on hold.
2. Enter the number you want to transfer the call to, and then press  or the **Send** soft key.
3. Press the **Transfer** soft key when the second party answers the call.

Call Forward

1. Tap **Menu->Call Feature->Call Forward**.
2. Select the desired forward type:
 - Always Forward**-----Incoming calls are forwarded unconditionally.
 - Busy Forward**-----Incoming calls are forwarded when the phone is busy.
 - No Answer Forward**-----Incoming calls are forwarded when the phone is not answered after a preset time period.
3. Enter the number you want to forward the call to. For **No Answer Forward**, enter the ring time to wait before forwarding.


Call Conference

1. Press the **Conference** soft key during an active call. The call is placed on hold.
2. Enter the number of the second party, and then press the **Send** soft key.
3. Press the **Conference** soft key again when the second party answers. All parties are now in the conference.
4. Hang up the call to disconnect all parties.


Note: You can split the conference call into two individual calls by tapping the **Split** icon.

Yealink

IP Video Phone VP530



Quick Reference Guide (v70.1)



LEDs

Table 1 Power Indicator LED

LED Status	Description
Solid green	The phone is powered on.
Off	The phone is powered off.

Table 2 Event Indicator LED

LED Status	Description
Solid green	The phone is in dialing, connecting or talking state.
Fast flashing green	The network is unavailable. The phone receives an incoming call. There is no available account.
Slow flashing green	The phone is in upgrading state. The call on the phone is on mute or on hold. The phone receives new message, missed call or forwarded call.
Off	The phone is in idle state.


Placing a Call

1. Using the handset:

Pick up the handset.

Enter the number, and then press the **Send** soft key.

2. Using the speakerphone:

With the handset on-hook, press .

Enter the number, and then press the **Send** soft key.

3. Using the headset:

With the headset connected.

Enter the number, and then press the **Send** soft key.

Answering a Call

1. Using the handset:

Pick up the handset.

2. Using the speakerphone:

Press .

3. Using the headset:

With the headset connected and press the **Answer** soft key.

Note: You can ignore an incoming call by pressing the **Reject** soft key.

Ending a Call

1. Using the handset:

Hang up the handset or press the **End Call** soft key.

2. Using the speakerphone:

Press  or the **End Call** soft key.

3. Using the headset:


Press the **End Call** soft key.

Redialing a Call

1. Press  to enter the **Dialed Calls** list.

2. Press  or  to switch the pages and then tap the desired entry.

Starting/Stopping the Video

Press  to start/stop the near-site video during a video call.

Speed Dial

To configure a speed dial key:

1. Tap **Menu**->**Call Feature**->**DSS Keys**->**Memory Keys** (or **Line Keys**).

2. Tap the desired DSS key.


3. Select **Speed Dial** from the pull-down list of **Type** and the desired line from the pull-down list of **Account ID**, enter the number in the **Value** field.

4. Press the **Save** soft key to accept the change.

To use the speed dial key:

Tap the speed dial key to dial out the preset number.

Volume Adjustment

Press  or  to adjust the volume during a call.